



**General Notes**

Build: (1) For Support Wall/Wagon Level  
Cut List. 2x12 Lumber: \*\*Adjust for Nominal Thickness Differences\*\*

- (1) 12'-0"
- (1) 8'-0"
- (1) 4'-0"
- (4) 8'-5-3/8"
- (7) 7'-9"

Luan:  
(2) 4'x8'

**Instructions.**

- Cut Lumber
- Screw cut 2x boards with (6) 3" screws at each intersection.
- Screw 1/4" Luan with 1" screws every 1' and hitting each corner/toggle.

Show Name Noises Off 2019		
Reference 1/4"=1'	Drawn By Scott Bedell	Date 09/04/19
CAD File Name Support Wall F		